

## Proofmaster / Proofmaster -Plus & Printfactory

Liste der unterstützten Drucker / List of supported printers (September 2021):

<b>Hersteller:</b>	<b>Model:</b>	<b>Typ:</b>						
<b>Canon</b>	iPF Pro	PRO- 1000 / 2000 / 4000 / 4000S / 4100S / 6000 / 6000S 520 / 540 / 540S / 560 / 560S						
	iPF	iPF- 5100 / 6000S / 6100 / 6200 / 6300 / 6300S / 6400 / 6410 / 6450 / 6460 710 / 720 / 8000 / 8000S / 810 / 815 / 820 / 8300 / 8300S / 8310 / 8310S 8400 / 9000 / 9000S / 9100 / 9410 / 9410S						
	I	i6500 / i9100 / i990 / i9900 / i9950						
<b>Epson</b>	Stylus Pro	3800 (als 3880) / 3880 4800 / 4880 / 4900 GS 6000 7800 / 7880 / 7890 / 7900 / WT 7900 9800 / 9880 / 9890 / 9900 / 11880						
		SureColor SC-P	800 / 800 DTP / 5000 STD-V-Spectro / 6000 STD-Spectro / 7000 STD-V-Spectro / 7500 STD-Spectro 8000 STD-Spectro / 9000 STD-V-Spectro / 9500 STD-Spectro / 10000 / 20000					
		SureColor SC-S SureColor SC-T	30600 / 30610 / 40600 / 40610 / 80600 3000 / 3200 / 5000 / 5200 / 5200D / 7000 / 7200 / 7200D					
	<b>HP</b>	DesignJet	50 PS 5000 / 5000 UV / 5100 / 5500 / 5500 UV T 7100 / T 7200 Z 2100 / Z 3100 Photo / Z 3200 Photo / Z 5200 / Z 5400 / Z 5600 Z 6 / Z 6 dr / Z 6100 Photo / Z 6200 / Z 6600 / Z 6800 / Z 9 / Z 9 dr					
			<b>Mutoh</b>	ValueJet	1204 / 1304 / W 1324 / X / XS 1604 / 1608 H / 1614 / 1617 H / 1618 1624 / W / WX 1638 / W / WX / X 1938WX / WX-K4 2638 / X			
<b>Mimaki</b>					CJV JFX JV	150 / 300 / 30-60 / 30-100 / 30-130 / 30-160 1610 / 1615 Plus / 1631 / 1631 Plus / 200 / 500 150 / 300 / 1300 3 / 3-130 SPII / 3-160 SPII / 3-250 SP / 34-260		
						<b>Roland</b>	LEC LEF  RS SC SJ	EJ-640 / FH-740 / 300 / 330 / 540 12 / 20 / 300 LEJ 640 / RA 640 / RE 640 / RF 640 540 / 540S / 640 / 640S 540 / 545 EX / 540 EXW 1000