

Proofmaster / Proofmaster -Plus & Printfactory

Liste der unterstützten Drucker / List of supported printers (03/2022):

Hersteller:	Model:	Typ:
Canon	iPF Pro	PRO- 1000 / 2000 / 4000 / 4000S / 4100S / 6000 / 6000S 520 / 540 / 540S / 560 / 560S
	iPF	iPF- 5100 / 6000S / 6100 / 6200 / 6300 / 6300S / 6400 / 6410 / 6450 / 6460 710 / 720 / 8000 / 8000S / 810 / 815 / 820 / 8300 / 8300S / 8310 / 8310S 8400 / 9000 / 9000S / 9100 / 9410 / 9410S
	I	i6500 / i9100 / i990 / i9900 / i9950
Epson	Stylus Pro	3800 (als 3880) / 3880 4800 / 4880 / 4900 GS 6000 7800 / 7880 / 7890 / 7900 / WT 7900 9800 / 9880 / 9890 / 9900 / 11880
	SureColor SC-P	800 / 800 DTP / 900 (nur für Windows-Version) 5000 STD-V-Spectro / 6000 STD-Spectro / 7000 STD-V-Spectro / 7500 Spectro 8000 STD-Spectro / 9000 STD-V-Spectro / 9500 Spectro / 10000 / 20000
	SureColor SC-S	30600 / 30610 / 40600 / 40610 / 80600
	SureColor SC-T	3000 / 3200 / 5000 / 5200 / 5200D / 7000 / 7200 / 7200D
HP	DesignJet	50 PS 5000 / 5000 UV / 5100 / 5500 / 5500 UV T 7100 / T 7200 Z 2100 / Z 3100 Photo / Z 3200 Photo / Z 5200 / Z 5400 / Z 5600 Z 6 / Z 6 dr / Z 6100 Photo / Z 6200 / Z 6600 / Z 6800 / Z 9 / Z 9 dr / Z 9+ Pro
Mutoh	ValueJet	1204 / 1304 / W 1324 / X / XS 1604 / 1608 H / 1614 / 1617 H / 1618 1624 / W / WX 1638 / W / WX / X 1938WX / WX-K4 2638 / X
Mimaki	CJV	150 / 300 / 30-60 / 30-100 / 30-130 / 30-160
	JFX	1610 / 1615 Plus / 1631 / 1631 Plus / 200 / 500
	JV	150 / 300 / 1300 3 / 3-130 SPII / 3-160 SPII / 3-250 SP / 34-260
Roland		EJ-640 / FH-740 /
	LEC	300 / 330 / 540
	LEF	12 / 20 / 300 LEJ 640 / RA 640 / RE 640 / RF 640
	RS	540 / 540S / 640 / 640S
	SC	540 / 545 EX / 540 EXW
	SJ	1000